



SUN-AGE
PV MOUNTING SYSTEMS

Respecting your world


BEE33

ISTRUZIONI DI MONTAGGIO

INSTALLATION MANUAL

BEE33


by **SUN-AGE**













LEGENDA

KEY

RIF.	DESCRIZIONE/DESCRIPTION
A	BEE33
S	Morsetto Laterale / Lateral Clamp
U	Morsetto Centrale / Central Clamp
T	Tassello / Dowel
V	Vite / Screw
G	Piastrina con plastica / Hammer Nut with plastic gasket
M	Molla / Spring




STEP 1a





STEP 1_b

6





7





8



9




10







STEP 2

INTERASSE


CENTER TO CENTER DISTANCE




STEP 3



STEP 4







Via Groppelle 13 - 36064 COLCERESA (VI)
Tel. +39 0424478028 - info@sun-age.it
www.sun-age.it

La Ditta si riserva di apportare le modifiche che riterrà opportune senza darne preavviso, per esigenze tecniche o commerciali e non si assume responsabilità per eventuali errori e inesattezze sul contenuto di questo manuale. È vietata la riproduzione anche parziale di fotografie, disegni e testi. I trasgressori saranno perseguiti a norma di legge. I dati e le misure forniti hanno valore indicativo.